
METEOR


M IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS

IMPORTANT SAFETY INFORMATION. READ AND FOLLOW ALL SAFETY INSTRUCTIONS. Before wiring to power supply and during servicing or relamping, turn off power at fuse or circuit breaker. All servicing or relamping must be performed by qualified service personnel. Product must be grounded to avoid potential electric shock or other potential hazard. Product must be at locations and at heights and in a manner consistent with its intended use, and in compliance with Electrical Code and local codes.

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE.




METE₂R




Step 1

Remove bracket and wire clamp assembly from catenary by unscrewing long screws, washers and nuts.










Step 3

Pull cables through catenary and screw wire clamp.




Step 4

Place catenary with wire clamp inside bracket and refasten with long screws.

 METEOR LIGHTING
 P: 213.255.2060
 F: 213.596.3704
 www.meteor-lighting.com
 Page


 *METEOR LIGHTING reserves the right to make changes to this product at any time without prior notice and such modification shall be effective immediately.





Step 5


Lift luminaire and make electrical connections between fixture and power cable.



Step 6

Feed Power Cable through fixture. Twist and Lock to fasten luminaire to catenary. Secure fixture with 2 screws on either side.





Step 7 Complete Installation.

METE^OR

Wiring Diagram

0-10V / Superior 0-10V

LED Fixture	Blue(Neutral) White(Neutral)	-
	Brown(Line) Black(Line)	
		AC Input
	Blue (Positive)	
	Gray/Pink(Negative)	
	, 0-10V Dimming	-